

Thapar Institute of Engineering & Technology (Deemed to be University)

Bhadson Road, Patiala, Punjab, Pin-147004 Contact No.: +91-175-2393201


Email: info@thapar.edu



Isomorphous Binary Phase Diagram

- □Two component system
- ☐ Complete solubility in liquid as well as in solid
- □ Also know as solid solution systems

Expect T_m of solution to lie in between T_m of two pure components



For a pure component, complete melting occurs before T_m increases (sharp phase transition)

But for multicomponent systems, there is usually a coexistence of liquid and solid.

Criteria for formation of Solid Solutions

W. Hume–Rothery rules


- > Both elements/compound should have the same crystal structure
- > Atomic size difference less than 15% (atomic/ionic radii similar)
- > Less difference in electronegativity values
- ➤ Same valency

Ni and Cu are totally soluble in one another for all proportions.

	Crystal Structure	electroneg	<i>r</i> (nm)
Ni	FCC	1.9	0.1246
Cu	FCC	1.8	0.1278



Isomorphous Binary Phase Diagram




What can we learn from this phase diagram?

- 1.Phase(s) present
- 2. Composition of those phases
- 3. Amount of the phases

Solidus - Temperature where alloy is completely solid. Above this line, liquefaction begins.

Liquidus - Temperature where alloy is completely liquid. Below this line, solidification begins.

- □ Changing T can change # of phases: path A to B.
- □Changing C_o can change # of phases: path B to D.




Determination of phase(s) present

Rule 1: If we know T and Co, then we know:

 how many phases and which phases are present.

Examples

- 1. At Temperature 1225 °C and C_o = 30 wt. % Ni, no of phases present: L + a. (point A in phase diagram).
- 2. At Temperature 1150° C and C_{\circ} = 60 wt. % Ni, no of phases present: a. (point B in phase diagram).



Composition of phases


Rule 2: If we know T and Co, then we know:-the composition of each phase.

Example

Alloy composition (C_o)= Cu 50 wt. % Ni


- 1. At temperature $T_A = 1450^{\circ}C$, only liquid phase is present and $C_L = C_{\circ} (=50 \text{ wt.}\%)$ Ni).
- 2. At temperature $T_B = 1275^{\circ}C$, Both a and L present, $C_L = 40$ wt. % Ni and $C_a = 60$ wt. % Ni. Use tie line to identity these composition.
- 3. At temperature $T_D = 1190^{\circ}C$, only solid (a) present $C_a = C_o$ (= 50 wt. %Ni)

A tie line is constructed across the two-phase region at the temperature of the alloy




The Lever Rule

The lever rule derived from mass balance gives the relative amounts of the co-existing phases. It is derived as Tie line treated as lever arm, with the fulcrum as the overall composition.



Mass fractions be represented by W_L and W_α for the respective phases.

$$W_{L} = \frac{M_{L}}{M_{L} + M_{\alpha}} = \frac{S}{R + S} = \frac{C_{\alpha} - C_{0}}{C_{\alpha} - C_{L}}$$





Interpretation of Phase Diagram

 $C_0 = 35$ wt.% Ni, $C_0 = 42.5$ wt.% Ni, and $C_L = 31.5$ wt.% Ni

$$W_{\alpha} = \frac{R}{R+S} = \frac{C_0 - C_L}{C_{\alpha} - C_L}$$

$$W_L = \frac{42.5 - 35}{42.5 - 31.5} = 0.68$$

$$W_{\alpha} = \frac{35 - 31.5}{42.5 - 31.5} = 0.32$$

For an alloy consisting of a and β phases, the volume fraction of the a phase,

is defined as

$$V_{\alpha} = \frac{V_{\alpha}}{V_{\alpha} + V_{\beta}}$$

$$V_{\alpha} + V_{\beta} = 1$$

a phase volume fraction-dependence on volumes of a and β phases




Development of microstructure

Microstructures will vary on the cooling rate (i.e. processing conditions)

Equilibrium Cooling

- Very slow cooling to allow phase equilibrium to be maintained during the cooling process.
- 2. Colling rate << diffusion time.






Development of microstructure in isomorphous alloys

Non-equilibrium Cooling

- 1. Fast cooling does not allow to allow phase equilibrium to be maintained during the cooling process.
- 2. Colling rate >> diffusion time.

The centre of each grain, which is the first part to freeze, is rich in the high-melting element (e.g., nickel for this Cu-Ni system), whereas the concentration of the low-melting element increases with position from this region to the grain boundary. This is termed a cored structure, and gives rise to less than the optimal properties.




Composition (wt% Ni)



Development of microstructure

- C_{α} changes as we solidify.
- Cu-Ni case: First α to solidify has C_{α} = 46 wt% Ni. Last α to solidify has C_{α} = 35 wt% Ni.
- Slow rate of cooling:
 Equilibrium structure
 Fast rate of cooling:
 Cored structure





- 1. Phase diagrams are useful tools to determine:
 - -- the number and types of phases present,
 - -- the composition of each phase,
 - -- and the weight fraction of each phase given the temperature and composition of the system.
- 2. Isomorphous phase diagrams has same structure and same morphology without any solubility limit.
- 3. The microstructure of an alloy depends on
 - -- its composition, and
 - -- whether or not cooling rate allows for maintenance of equilibrium.

